

3040 Electronic Reset

In case of a loss of the current supply, caused by oxidized or loose battery contacts, humidity or a short-circuit, the arithmetic operation of the processor can be disturbed. Those leads to internal operation errors and in consequence to all possible malfunctions.

(Errors in date, Vario, height etc..)

The keyboard can be blocked or the 3040 switches off suddenly.

In this case a RESET must be made, if one takes out both 9V batteries and after approx. 20 minutes insert them again.

If the internal data are successfully reset, the 3040 starts the initialization with

hh:nn 12:00 dd:nn 17:06 YYYY 1994 (ev. 1992)

Now the correct date and the current time can be set again.

All 3040 functions should run perfectly again. Otherwise the equipment must be returned for inspection.